

## JET VAC POOL CLEANER

### JET VAC POOL CLEANER



Jet-Vac features forward and reverse cycles to ensure complete pool coverage on any surface without getting stuck in corners. Propulsion and cleaning is achieved purely by jets of water. Wheels are free spinning and are not connected to turbines, drive belts or gears. Jet-Vac requires a dedicated plumbing line and is powered by the Aqua-Quip booster pump.

| CODE   | DESCRIPTION   |
|--------|---|
| LJV101 | Jet Vac Head and Hose Set only                              |
| LJV104 | Jet Vac Head Only   |
| LJV105 | Jet Vac Hose Set Complete                                   |
| LJV108 | Jet Vac Platinum Package Consists of LJV101, LJV301, DCC240 |



## JET VAC POOL CLEANER SPARE PARTS

### JET VAC HEAD PARTS

| CODE   | DESCRIPTION                              |       |
|--------|--|-------|
| LJV001 | Adaptor                                  | JV3   |
| LJV002 | Venturi Shell                            | JV2   |
| LJV060 | Screw                                    | JVG10 |
| LJV003 | Shell Float                              | JV4   |
| LJV004 | Bottom Plate                             | JV5   |
| LJV013 | Pusher Jet Nozzle                        | JV17  |
| LJV014 | O Ring                                   | JV18  |
| LJV015 | Pusher Jet Nozzle Holder                 | JV19  |
| LJV016 | Wheel                                    | JV21  |
| LJV017 | Wheel Hub                                | JV22  |
| LJV048 | Bearing                                  | LG35B |
| LJV050 | Wheel Kit ( 1 Wheel, 1 Hub, 2 Bearings ) | JV207 |
| LJV023 | Screw (Front Wheel)                      | JV43  |
| LJV024 | Screw (Pusher Jet)                       | JV44  |
| LJV025 | Nut (Front Wheel)                        | JV45  |
| LJV026 | Screw (Bottom Plate)                     | JV46  |
| LJV646 | Screw                                    | JV46S |
| LJV027 | Screw (Back Wheels)                      | JV48  |
| LJV649 | Tail Mender                              | JV49  |
| LJV037 | Side Wheel Complete                      | JV62  |
| LJV039 | Side Wheel                               | JV64  |
| LJV611 | Brass Weight - Large                     | JV70  |
| LJV613 | Brass Weight Kit (2 x Small)             | JV71  |
| LJV054 | Float Cover Adjustable Button            | PJ4B  |
| LJV055 | Deflector Plate Assembly                 | JV2B  |
| LJV047 | O Ring                                   | LF07  |

|   |
|---|
| <b>JET VAC POOL CLEANER SPARE PARTS</b> |
|---|

**JET VAC INTERNAL HEAD PARTS**

| CODE   | DESCRIPTION  |       |
|--------|--|-------|
| LJV051 | Pin ( For Bottom Plate)                              | JV6   |
| LJV005 | Gear   | JV7   |
| LJV006 | Propellor  | JV8   |
| LJV007 | Spacer   | JV9   |
| LJV008 | O Ring (Shell)                                       | JV11  |
| LJV049 | Tune Up Kit ( 4 Gear, 1 Propellor, 3 Pins, 1 Spacer) | JV204 |

**JET VAC DEBRIS BAG ASSEMBLY**

| CODE   | DESCRIPTION               |      |
|--------|---------------------------|------|
| LJV053 | Gasket For Funnel Adaptor | JV29 |
| LJV018 | Funnel Adaptor            | JV30 |
| LJV019 | Mesh Bag w/ Lock Ring     | JV31 |
| LJV020 | Fine Bag w/ Lock Ring     | JV32 |

**FRONT ROLLER ASSEMBLY PARTS**

| CODE   | DESCRIPTION                         |       |
|--------|-------------------------------------|-------|
| LJV009 | Roller Arm                          | JV12  |
| LJV010 | Nose Wheel                          | JV13  |
| LJV011 | Nose Wheel Hub                      | JV14  |
| LJV012 | Stainless Steel Wheel               | JV15  |
| LJV063 | Wheel Hub for Stainless Steel Wheel | JV16  |
| LJV057 | Lock Washer                         | JV61  |
| LJV048 | Bearing                             | LG35B |
| LJV021 | Screw                               | JV41  |
| LJV022 | Nut                                 | JV42  |
| LJV023 | Screw                               | JV43  |
| LJV661 | Screw                               | JV43S |
| LJV025 | Nut                                 | JV45  |

**JET VAC SWEEP HOSE PARTS**

| CODE   | DESCRIPTION         |      |
|--------|---------------------|------|
| LJV028 | Disconnect Swivel   | JV50 |
| LJV031 | Sweep Hose Complete | JV52 |
| LJV032 | Hose Sleeve         | JV53 |
| LJV033 | Roller Ring         | JV54 |
| LJV034 | Hose Jet Collar     | JV55 |
| LJV035 | Hose Jet            | JV56 |

|   |
|---|
| <b>JET VAC POOL CLEANER SPARE PARTS</b> |
|---|


|                                |
|--------------------------------|
| <b>JET VAC FEED HOSE PARTS</b> |
|--------------------------------|

| CODE   | DESCRIPTION                         |       |
|--------|-------------------------------------|-------|
| LJV029 | Feed Hose First Section Dark Blue   | JV502 |
| LJV030 | Feed Hose Second Section Light Blue | JV503 |
| LJV036 | Float                               | JV57  |
| LJV045 | Mender Nut                          | LD02  |
| LJV046 | Swivel                              | LD05  |
| LJV056 | Quick Disconnect 16mm               | J28   |
| LJV040 | Pressure Tester without Gauge       | JVP8  |
| LJV058 | Starter Hose White                  | JV501 |


|  |
|--|
| <b>JET VAC WALL FITTING ASSEMBLIES</b> |
|--|

| CODE   | DESCRIPTION  |        |
|--------|--|--------|
| LJV064 | Wall Fitting Complete  | JVW22  |
| LJV065 | Screen for Bayonet Wall Fitting                                      | LLJV24 |
| LJV069 | O Ring for JVW22   | JV20   |
| LJV068 | Quick Disconnect Adaptor   | JV23   |
| LJV041 | Wall Fitting Complete c/w Adjustable Fitting                         | JVW1A  |
| LJV042 | Finger Screen  | JVW2   |
| LJV044 | Wall Fitting No Screen   | JVW3   |
| LJV070 | Pressure Release Assembly  | LL22   |
| LJV047 | O Ring   | LVF7   |
| YMP002 | Wall Adaptor 19mm Male to 40mm Female                                |        |
| YMP004 | Wall Adaptor 40mm Slip to 40mm Female for Jet Vac, Legend & Polaris  |        |
| YMP010 | Pressure Cleaner Flush-Fit Wall Adaptor for Concrete Pools           |        |
| YMP015 | Pressure Cleaner Flush-Fit Wall Adaptor for Vinyl & Fibreglass Pools |        |

## JET VAC POOL CLEANER SPARE PARTS




## JET VAC HOSE SPARE PARTS



| ITEM | CODE    | PART # | DESCRIPTION                   |
|------|---------|--------|-------------------------------|
| A    | LJV 068 | JV23   | Quick Disconnect Adaptor      |
| B    | LJV 065 | JV24   | Strainer Screen               |
| C    | LJV 069 | JV20   | O-Ring                        |
| D    | LJV 070 | JV25   | Pressure Release Assembly     |
| E    | LJV 064 | JVW22  | Bayonet Wall Fitting Complete |
| F    | LJV 045 | JVD15P | Mender Nut                    |
| G    | LJV 058 | JV501  | Starter Hose – White (0.6m)   |
| H    | LJV 046 | JVD5   | Swivel                        |
| I    | LJV 029 | JV502  | Feed Hose – Dark Blue (4.2m)  |
| J    | LJV 036 | JV57   | Float                         |
| K    | LJV 030 | JV503  | Feed Hose – Light Blue (4.9m) |
| L    | LJV 028 | JV50   | Disconnect Swivel             |
| M    | LJV 031 | JV52   | Sweep Hose Complete           |

## JET VAC WALL ADAPTORS



| CODE   | DESCRIPTION   |
|--------|---|
| YMP002 | Wall Adaptor - 19mm Male to 40mm Female                               |
| YMP004 | Wall Adaptor - 40mm Slip to 40mm Female for Jet Vac, Legend & Polaris |
| YMP010 | Pressure Cleaner Flush-Fit Wall Adaptor for Concrete Pools            |
| YMP015 | Pressure Cleaner Flush-Fit Wall Adaptor for Vinyl & Fibreglass Pools  |



### Rainbow Pool Products

PO Box 2388, Mansfield Qld 4122

Telephone STD 61-7-3849 5385

Facsimile STD 61-7-3849 5384

Email: [info@rainbowpoolproducts.com.au](mailto:info@rainbowpoolproducts.com.au)

Web: [www.rainbowpoolproducts.com.au](http://www.rainbowpoolproducts.com.au)